

SIP CARRIER – 1: PROVEEDOR ENTEL.

PROVIDER NAME (20 Characters): ENTEL (opcional)

SIP SERVER NAME (100 Characters) ENTEL (opcional)

SIP SERVER IP ADDRESS: XXX.XXX.XXX.XXX (rango indicado por ENTEL)

SIP SERVER PORT NUMBER: 5060 (No cambia)

SIP SERVER DOMAIN: opcional

SUBSCRIBER NUMBER: XXXXXXXXX (Número cabecera)

ACCOUNT: (Generalmente se utiliza un código de 4 dígitos)

USER NAME: 1234

AUTHENTICATION ID: 1234

AUTHENTICATION PASSWORD: 1234

SIP Trunk Property

PBX Configuration > 3.Trunk > 7.SIP Trunk Property

Common	SIP Carrier - 1	SIP Carrier - 2
SIP Registration Status		
Not Registered		
Provider Name (20 characters)		
ENTEL		
SIP Server Name (100 characters)		
ENTEL		
SIP Server IP Address		
192 . 168 . 100 . 200		
SIP Server Port Number		
5060 (1 - 65535)		
SIP Service Domain (100 characters)		
ENTEL [0-9 a-z A-Z - .]		
Subscriber Number		
228260000 [0-9 # *]		
Account		
User Name (64 characters)		
1234		
Authentication ID (64 characters)		
1234		
Authentication Password (32 characters)		
1234		

REGISTER ABILITY: disable

Register		
Register Ability	☐ Enable	☒ Disable

VOICE: Priority 1st: G729A; 2nd: G711A; 3rd: none

Voice	
IP Codec Priority 1st	☐ G.711A ☐ G.711Mu ☒ G.729A
IP Codec Priority 2nd	☒ G.711A ☐ G.711Mu ☐ G.729A ☐ None
IP Codec Priority 3rd	☐ G.711A ☐ G.711Mu ☐ G.729A ☒ None

Los otros parámetros quedan por defecto, solo se configura lo indicado.

DDI TABLE: rango indicado por ENTEL (Ellos trabajan generalmente a 3; 4 ó 9 dígitos).

DDI Table					
No.	DDI Number [0-9 # *]	Name	Destination Day	Destination Lunch	Destination Night
1	000		101/		
2	0000		101/		
3	228260000		101/		
4					
5					

EXTENSION CLIP SIP CARRIER – 1: OPCIONAL: Indica el número que envías a la pública (ejemplo: 228260 + Número de extensión (103)=228260103).

Port

PBX Configuration > 2.Extension > 1.Port

Extension Number

103

[0-9]

Extension Name

CLIP

SIP Carrier - 1

228260103

[0-9]

SIP Carrier - 2

[0-9]