

Precautions when using infrared lighting (IR-LED)

When using the IR-LEDs in new compact dome camera, it is recommended to install the camera so that the four IR-LEDs can be seen from the outside of the main cover as refer to the following pictures.

Models:

WV-S3131L/S3111L/S3531L/S3531L/S3531LM/S3531LM

(Recommended camera installation angle)



None of four IR-LEDs are hidden by the main cover.

(The photo image which removed the dome cover.)

(Non recommended camera installation angle)



Depending on the installation direction (ceiling) of the camera, some of the four IR-LEDs may be hidden under the main cover, and the image may be dark due to the lack of light of the IR LED when monitoring in a dark environment.

Two IR-LEDs are hidden under the main cover.

(The photo image which removed the dome cover.)