

# Precautions Required When Cameras Are Used with an External Power Supply

When using an external power supply for cameras, be sure to connect the "PoE incompatible cable" and "cable coupler" between the camera and WJ-PC200 (camera side unit).

